



Grazie per aver scelto il nostro prodotto!



SOUNDSATION SX37-SB XILOFONO 37 NOTE - MANUALE D'USO

Grazie per aver scelto il nostro xilofono SX-37SB. Progettato per studenti, educatori e musicisti in movimento, questo strumento combina una intonazione impeccabile con una struttura leggera e facilmente trasportabile. Prima dell'utilizzo, leggere attentamente questo manuale per garantire un uso corretto e duraturo.

CONTENUTO DELLA CONFEZIONE

- 1 xilofono SX-37SB (barre in palissandro, telaio in pino)
- 2 coppie di battenti
- 1 supporto a X ripiegabile in metallo
- 1 borsa per il trasporto
- 1 manuale d'istruzioni

SPECIFICHE TECNICHE DEL PRODOTTO

- Note: 37
- Estensione: 3 ottave (DO4 – DO7)
- Barre: Palissandro selezionato, intonate con precisione
- Telaio: Pino leggero e resistente
- Supporto: In metallo, ripiegabile a X
- Accessori: Borsa per il trasporto, 2 coppie di battenti inclusi

MODI D'USO

- Aprire il supporto a X su una superficie stabile e bloccarlo alla posizione desiderata.
- Posizionare lo xilofono sul supporto in modo che sia ben centrato e stabile.
- Usare i battenti forniti per suonare le barre, evitando colpi eccessivamente forti per preservare l'intonazione.
- Dopo l'uso, ripiegare il supporto e riporre lo strumento nella borsa per facilitarne il trasporto.
- Conservare in un ambiente asciutto per preservare le parti in legno.

MANUTENZIONE E PULIZIA

- Pulire le barre con un panno asciutto e morbido dopo ogni utilizzo.
- Evitare prodotti chimici o panni umidi per non danneggiare il palissandro.
- Controllare periodicamente il supporto per assicurarsi che sia stabile e in buone condizioni.
- Conservare lo strumento nella borsa inclusa quando non in uso, per proteggerlo da polvere, umidità e urti.

AVVERTENZE SPECIFICHE DEL PRODOTTO

- Non applicare forza eccessiva sulle barre.
- Evitare l'esposizione a temperature estreme o a fonti di umidità.
- Utilizzare solo i battenti inclusi o altri compatibili per xilofoni a barre in legno.
- Assicurarsi che il supporto sia completamente aperto e stabile prima dell'uso.
- Grazie per aver scelto il nostro SX-37SB: uno strumento dal suono accurato e pensato per essere sempre con voi.

AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPSR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneggiato o con parti mancanti.
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio.

Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso.



Inquadra il QR-Code per scaricare la documentazione del prodotto.

Smaltire il prodotto e il suo imballaggio in modo responsabile, secondo le normative locali per il riciclo e la protezione ambientale

Made in/Prodotto in/Hecho en China for SoundSation
Imported by/Importato da/Importato de in EU by
FREXEXPORT SpA

Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy
frenexport.it - contact@frenexport.it

SoundSation® is a registered trademark of FREXEXPORT SPA - Italy
SoundSation® è un marchio di fabbrica registrato della FREXEXPORT SPA - Italy





Thank you for choosing our product!



SOUNDSATION SX37-SB 37 KEYS XYLOPHONE - USER MANUAL

Thank you for choosing our SX-37SB xylophone. Designed for students, educators, and mobile musicians, this instrument combines precise tuning with a lightweight, highly portable structure. Please read this manual carefully before use to ensure safe handling and long-lasting performance.

PACKAGE CONTENTS

- 1 SX-37SB xylophone (rosewood bars, pine frame)
- 2 pairs of mallets
- 1 foldable X-style metal stand
- 1 carrying bag
- 1 instruction manual

PRODUCT SPECIFICATIONS

- Notes: 37
- Range: 3 octaves (C4 – C7)
- Bars: Precisely tuned rosewood
- Frame: Lightweight, durable pine
- Stand: Foldable metal X-stand
- Accessories: Carrying bag, 2 pairs of mallets included

USAGE INSTRUCTIONS

- Open the X-style stand on a flat, stable surface and lock it into position.
- Place the xylophone securely on top of the stand, centered and balanced.
- Use the included mallets to play the bars—avoid striking too hard to maintain tuning accuracy.
- After playing, fold the stand and store the instrument in the carrying bag for easy transport.
- Keep the instrument in a dry environment to protect the wooden components.

MAINTENANCE AND CLEANING

- Wipe the bars with a soft, dry cloth after each use.
- Avoid using chemicals or wet cloths on the rosewood surface.
- Periodically check the stand for stability and wear.
- Store the instrument in the provided bag when not in use to protect it from dust, moisture, and impacts.

PRODUCT-SPECIFIC WARNINGS

- Do not apply excessive force to the bars.
- Avoid exposure to extreme temperatures or moisture.
- Use only the included mallets or other mallets designed for wooden bar xylophones.
- Always ensure the stand is fully open and stable before playing.
- Thank you for choosing the SX-37SB—a precisely tuned, travel-ready instrument you can rely on.

GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use.

For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.

Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection

Made in/Prodotto in/Hecho en China for SoundSation
Imported by/Importato da/Importato de in EU by
FRENEXPOR SpA

Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy
frenexport.it - contact@frenexport.it

SoundSation® is a registered trademark of FRENEXPOR SPA - Italy
SoundSation® è un marchio di fabbrica registrato della FRENEXPOR SPA - Italy

