



Grazie per aver scelto il nostro prodotto!



SOUNDSATION SX37-SB RULLANTE DA BANDA - MANUALE D'USO

Grazie per aver scelto il nostro xilofono SX-37SB. Progettato per studenti, educatori e musicisti in movimento, questo strumento combina una intonazione impeccabile con una struttura leggera e facilmente trasportabile. Prima dell'utilizzo, leggere attentamente questo manuale per garantire un uso corretto e duraturo.

CONTENUTO DELLA CONFEZIONE

- 1 xilofono SX-37SB (barre in palissandro, telaio in pino)
- 2 coppie di battenti
- 1 supporto a X ripiegabile in metallo
- 1 borsa per il trasporto
- 1 manuale d'istruzioni

SPECIFICHE TECNICHE DEL PRODOTTO

- Note: 37
- Estensione: 3 ottave (DO4 – DO7)
- Barre: Palissandro selezionato, intonate con precisione
- Telaio: Pino leggero e resistente
- Supporto: In metallo, ripiegabile a X
- Accessori: Borsa per il trasporto, 2 coppie di battenti inclusi

MODI D'USO

- Aprire il supporto a X su una superficie stabile e bloccarlo alla posizione desiderata.
- Posizionare lo xilofono sul supporto in modo che sia ben centrato e stabile.
- Usare i battenti forniti per suonare le barre, evitando colpi eccessivamente forti per preservare l'intonazione.
- Dopo l'uso, ripiegare il supporto e riporre lo strumento nella borsa per facilitarne il trasporto.
- Conservare in un ambiente asciutto per preservare le parti in legno.

MANUTENZIONE E PULIZIA

- Pulire le barre con un panno asciutto e morbido dopo ogni utilizzo.
- Evitare prodotti chimici o panni umidi per non danneggiare il palissandro.
- Controllare periodicamente il supporto per assicurarsi che sia stabile e in buone condizioni.
- Conservare lo strumento nella borsa inclusa quando non in uso, per proteggerlo da polvere, umidità e urti.

AVVERTENZE SPECIFICHE DEL PRODOTTO

- Non applicare forza eccessiva sulle barre.
- Evitare l'esposizione a temperature estreme o a fonti di umidità.
- Utilizzare solo i battenti inclusi o altri compatibili per xilofoni a barre in legno.
- Assicurarsi che il supporto sia completamente aperto e stabile prima dell'uso.
- Grazie per aver scelto il nostro SX-37SB: uno strumento dal suono accurato e pensato per essere sempre con voi.

AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPSR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneggiato o con parti mancanti
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio. Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso.



Inquadra il QR-Code per scaricare la documentazione del prodotto.

Smaltire il prodotto e il suo imballaggio in modo responsabile, secondo le normative locali per il riciclo e la protezione ambientale

Made in/Prodotto in/Hecho en China for SoundSation
Imported by/Importato da/Importato de in EU by
FRENEXPORt SpA
Via Enzo Ferrari,10 - 62017 Porto Recanati – Italy
frenexport.it - contact@frenexport.it

SoundSation® is a registered trademark of FRENEXPORt SPA - Italy
SoundSation® è un marchio di fabbrica registrato della FRENEXPORt SPA - Italy





Thank you for choosing our product!



SOUNDSATION SX37-SB MARCHING SNARE DRUM - USER MANUAL

Thank you for choosing our SX-37SB xylophone. Designed for students, educators, and mobile musicians, this instrument combines precise tuning with a lightweight, highly portable structure. Please read this manual carefully before use to ensure safe handling and long-lasting performance.

PACKAGE CONTENTS

- 1 SX-37SB xylophone (rosewood bars, pine frame)
- 2 pairs of mallets
- 1 foldable X-style metal stand
- 1 carrying bag
- 1 instruction manual

PRODUCT SPECIFICATIONS

- Notes: 37
- Range: 3 octaves (C4 – C7)
- Bars: Precisely tuned rosewood
- Frame: Lightweight, durable pine
- Stand: Foldable metal X-stand
- Accessories: Carrying bag, 2 pairs of mallets included

USAGE INSTRUCTIONS

- Open the X-style stand on a flat, stable surface and lock it into position.
- Place the xylophone securely on top of the stand, centered and balanced.
- Use the included mallets to play the bars—avoid striking too hard to maintain tuning accuracy.
- After playing, fold the stand and store the instrument in the carrying bag for easy transport.
- Keep the instrument in a dry environment to protect the wooden components.

MAINTENANCE AND CLEANING

- Wipe the bars with a soft, dry cloth after each use.
- Avoid using chemicals or wet cloths on the rosewood surface.
- Periodically check the stand for stability and wear.
- Store the instrument in the provided bag when not in use to protect it from dust, moisture, and impacts.

PRODUCT-SPECIFIC WARNINGS

- Do not apply excessive force to the bars.
- Avoid exposure to extreme temperatures or moisture.
- Use only the included mallets or other mallets designed for wooden bar xylophones.
- Always ensure the stand is fully open and stable before playing.
- Thank you for choosing the SX-37SB—a precisely tuned, travel-ready instrument you can rely on.

GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use.

For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.

Made in/Prodotto in/Hecho en China for SoundSation
Imported by/Importato da/Importato de in EU by
FRENEXPORt SpA
Via Enzo Ferrari, 10 - 62017 Porto Recanati – Italy
frenexport.it - contact@frenexport.it

SoundSation® is a registered trademark of FRENEXPORt SPA - Italy
SoundSation® è un marchio di fabbrica registrato della FRENEXPORt SPA - Italy

Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection

