



Grazie per aver scelto il nostro prodotto!



CHITARRA ACUSTICA SOUNDSATION - MANUALE UTENTE

Grazie per aver scelto una chitarra acustica SOUNDSATION. Ti consigliamo di leggere attentamente questo manuale per utilizzare al meglio il tuo strumento e farne un compagno fedele per il tuo viaggio nel mondo della musica.

CONTENUTO DELLA CONFEZIONE

All'interno della confezione troverai:

- una chitarra acustica accuratamente imballata per garantirne l'integrità durante il trasporto.

A seconda del modello acquistato, potrebbero essere inclusi accessori come borsa, tracolla, set di corde di ricambio e plettri. Controlla che tutti gli articoli siano presenti prima dell'uso.

ISTRUZIONI PER L'USO

Per suonare la chitarra, siediti in una posizione comoda mantenendo la schiena dritta. Appoggia la chitarra sulla coscia destra o utilizza una tracolla se preferisci suonare in piedi. Accorda lo strumento prima di ogni utilizzo per garantire il miglior suono possibile. Durante l'esecuzione, utilizza la mano sinistra per premere le corde sulla tastiera e la mano destra per pizzicare o arpeggiare le corde. Evita di applicare una pressione eccessiva sui tasti per non affaticare le dita. Nei modelli preamplificati utilizza l'uscita Jack/XLR per collegare la chitarra al tuo amplificatore/DI Box/Mixer e agisci sul preamplificatore per regolare il tuo suono, facendo attenzione ad evitare feedback indesiderati che potrebbero provocare fastidi o danni all'udito.

MANUTENZIONE E PULIZIA

Dopo ogni utilizzo, pulisci le corde con un panno morbido per rimuovere residui di sudore e sporco. Utilizza un panno in microfibra per la cassa armonica e il manico, evitando detergenti aggressivi che potrebbero danneggiare la finitura. Conserva la chitarra in un ambiente asciutto e lontano dalla luce diretta del sole per prevenire deformazioni del legno. Controlla periodicamente l'accordatura e sostituisci le corde usurate per mantenere un suono ottimale.

AVVERTENZE DI SICUREZZA

- Non esporre la chitarra a sbalzi termici o a umidità eccessiva per evitare danni strutturali.
- Evita di appoggiare oggetti pesanti sulla chitarra o di lasciarla cadere, poiché urti e pressioni possono compromettere l'integrità dello strumento
- Non tentare di effettuare riparazioni complesse in autonomia, ma affidati a un liutaio qualificato in caso di necessità.
- Conserva lo strumento nella sua custodia quando non in uso per proteggerlo dalla polvere e da eventuali danni accidentali.

Con la giusta cura e manutenzione, il tuo strumento ti accompagnerà in anni di performance musicali! Buon divertimento!

AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPSR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneggiato o con parti mancanti
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio.

Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso.



Inquadra il QR-Code per scaricare la documentazione del prodotto.



Made in/Prodotto in/Hecho en China for Soundsation
Imported by/Importato da/Importado de in EU by
FRENEXPORT SpA
Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy
frenexport.it - contact@frenexport.it
Soundsation® is a registered trademark of FRENEXPORT SPA - Italy
Soundsation® è un marchio di fabbrica registrato della FRENEXPORT SPA - Italy





Thank you for choosing our product!



SOUNDSATION ACOUSTIC GUITAR – USER MANUAL

Thank you for choosing a SOUNDSATION acoustic guitar. We recommend reading this manual carefully to make the most of your instrument and turn it into a faithful companion on your musical journey.

PACKAGE CONTENTS

Inside the package, you will find:

- 1 acoustic guitar carefully packed to ensure its integrity during transport.

Depending on the purchased model, accessories such as a gig bag, strap, spare string set, and picks may be included. Check that all items are present before use.

INSTRUCTIONS FOR USE

To play the guitar, sit in a comfortable position with your back straight. Rest the guitar on your right thigh or use a strap if you prefer playing while standing. Tune the instrument before each use to ensure the best possible sound. While playing, use your left hand to press the strings on the fretboard and your right hand to pluck or strum the strings. Avoid applying excessive pressure on the frets to prevent finger fatigue. In preamplified models, use the Jack/XLR output to connect the guitar to your amplifier, DI Box, or mixer, and adjust the sound through the preamp, being careful to avoid unwanted feedback that could cause discomfort or hearing damage.

MAINTENANCE AND CLEANING

After each use, clean the strings with a soft cloth to remove sweat and dirt residues. Use a microfiber cloth for the body and neck, avoiding harsh cleaners that could damage the finish. Store the guitar in a dry environment, away from direct sunlight, to prevent wood deformation. Regularly check the tuning and replace worn-out strings to maintain optimal sound quality.

SAFETY WARNINGS

- Do not expose the guitar to sudden temperature changes or excessive humidity to avoid structural damage.
- Avoid placing heavy objects on the guitar or letting it fall, as impacts and pressure can compromise the instrument's integrity.
- Do not attempt complex repairs on your own; instead, rely on a qualified luthier if necessary.
- Store the instrument in its case when not in use to protect it from dust and accidental damage.

With proper care and maintenance, your instrument will accompany you for years of musical performances! Have fun!

GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use.

For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.



Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection

Made in/Prodotto in/Hecho en China for Soundsation
Imported by/Importato da/Importado de in EU by
FRENEXPORT SpA
Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy
frenexport.it - contact@frenexport.it
Soundsation® is a registered trademark of FRENEXPORT SPA - Italy
Soundsation® è un marchio di fabbrica registrato della FRENEXPORT SPA - Italy