



SOUNDSATION ASTE MICROFONICHE - MANUALE UTENTE

Le aste microfoniche Soundsation sono progettate per offrire stabilità, praticità e affidabilità durante le performance dal vivo, in studio o nelle sale conferenze. Realizzate con materiali di alta qualità, garantiscono un supporto sicuro per il microfono, facilitando il posizionamento ottimale in base alle esigenze dell'utente. Questo manuale fornisce istruzioni su utilizzo, manutenzione e sicurezza per garantire prestazioni ottimali e una lunga durata.

UTILIZZO

- Assicurati che tutte le parti siano ben assemblate prima dell'uso. Se l'asta è telescopica o regolabile, agisci su sistema di bloccaggio (potrebbe variare a seconda del modello) per regolare l'altezza e/o l'inclinazione desiderata. Blocca lo stand agendo di nuovo sul sistema di bloccaggio.
- Imposta l'altezza adequata in base alla posizione del cantante o dell'oratore. Blocca sempre saldamente l'asta per evitare movimenti indesiderati.
- Fissa il supporto del microfono all'estremità dell'asta e verifica che sia ben saldo. Evita di applicare forza eccessiva durante il serraggio.
- Dopo ogni regolazione, controlla che l'asta sia stabile e che la base o i piedini siano posizionati correttamente per evitare ribaltamenti.

MANUTENZIONE

- Pulisci regolarmente l'asta con un panno morbido e asciutto. Se necessario, utilizza un panno leggermente umido con un detergente neutro.
- Controlla periodicamente le viti, le manopole di bloccaggio e i giunti per assicurarti che siano ben serrati e funzionanti.
- Se l'asta presenta parti mobili, applica occasionalmente una piccola quantità di lubrificante non aggressivo per garantire un movimento fluido.
- Quando non in uso, riponi l'asta in un luogo asciutto per prevenire danni da umidità o corrosione.

SICUREZZA

- Assicurati che l'asta sia posizionata su una superficie stabile e che la base sia completamente aperta per evitare cadute accidentali.
- Non appendere pesi aggiuntivi sull'asta o sul braccio telescopico per evitare squilibri e danni alla struttura.
- Evita che i cavi del microfono creino intralci o rischi di inciampo durante l'utilizzo.
- Durante il trasporto, chiudi e blocca l'asta per evitare danni ai meccanismi di regolazione.

AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPSR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneqgiato o con parti mancanti
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio.

Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso




Inquadra il QR-Code per scaricare la documentazione del prodotto.

Smaltire il prodotto e il suo imballaggio in modo responsabile, secondo le normative locali per il riciclo e la protezione ambientale



Soundsation® is a registered trademark of FRENEXPORT SPA - Italy Soundsation® è un marchio di fabbrica registrato della FRENEXPORT SPA - Italy







SOUNDSATION MICROPHONE STANDS - USER MANUAL

Soundsation microphone stands are designed to provide stability, practicality, and reliability during live performances, in the studio, or in conference rooms. Made with high-quality materials, they ensure secure support for the microphone, facilitating optimal positioning according to the user's needs. This manual provides instructions on usage, maintenance, and safety to ensure optimal performance and long-lasting durability.

USAGE

- Ensure that all parts are properly assembled before use. If the stand is telescopic or adjustable, loosen the locking knob, adjust the height or tilt as desired, and then tighten the knob again.
- Set the appropriate height based on the position of the singer or speaker. Always secure the stand firmly to prevent unwanted movement.
- Attach the microphone holder to the end of the stand and check that it is securely fastened. Avoid applying excessive force during tightening.
- For precise positioning, adjust the extendable boom arm and lock it in place using the appropriate knobs.
- After each adjustment, check that the stand is stable and that the base or feet are positioned correctly to prevent tipping over.

MAINTENANCE

- Regularly clean the stand with a soft, dry cloth. If necessary, use a slightly damp cloth with a mild deteraent.
- Periodically check the screws, locking knobs, and joints to ensure they are securely fastened and functioning properly.
- If the stand has moving parts, occasionally apply a small amount of non-aggressive lubricant to ensure smooth movement.
- When not in use, store the stand in a dry place to prevent damage from moisture or corrosion.

SAFETY

- Ensure that the stand is placed on a stable surface and that the base is fully opened to prevent accidental
- Do not hang additional weights on the stand or the boom arm to avoid imbalances and damage to the structure.
- Avoid microphone cables creating obstructions or tripping hazards during use.
- During transport, close and lock the stand to prevent damage to the adjustment mechanisms.

Thank you for choosing Soundsation! For more details and support, visit the official website or contact an authorized dealer.

GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use.

For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.

Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection





Made in/Prodotto in/Hecho en China for Soundsation Imported by/Importato da/Importato de in EU by FRENEXPORT SpA Via Enzo Ferrari, 10 - 62017 Porto Recanati – Italy frenexport.it - contact@frenexport.it Soundsation® is a registered trademark of FRENEXPORT SPA - Italy

Soundsation® è un marchio di fabbrica registrato della FRENEXPORT SPA - Italy