



Grazie per aver scelto il nostro prodotto!



## SOUNDSATION CAPOTASTO – MANUALE UTENTE

Il capotasto Soundsation è un accessorio essenziale per chitarristi e musicisti che desiderano modificare rapidamente la tonalità del proprio strumento. Disponibile in versioni universali o specifiche per chitarra acustica ed elettrica, può essere realizzato in metallo o plastica a seconda del modello. Questo manuale fornisce istruzioni su utilizzo, manutenzione e sicurezza per garantire prestazioni ottimali e una lunga durata.

### SPECIFICHE TECNICHE

- Tipologia: Universale o specifico per chitarra acustica/elettrica (a seconda del modello)
- Materiale: Metallo o plastica (a seconda del modello)
- Sistema di bloccaggio: A molla o a vite, per un fissaggio stabile e sicuro
- Rivestimento interno: In gomma o silicone per proteggere la tastiera dello strumento

### UTILIZZO

- Applicazione sul manico: Apri il capotasto e posizionalo sulla tastiera nella posizione desiderata.
- Fissaggio: Se il modello è a molla, premi e rilascia delicatamente per un fissaggio immediato. Se il modello è a vite, stringi gradualmente fino a ottenere una presa salda senza esercitare troppa pressione.
- Verifica della stabilità: Assicurati che il capotasto sia ben fissato e che tutte le corde suonino in modo chiaro senza vibrazioni indesiderate.
- Rimozione: Per rimuovere il capotasto, allenta la presa e solleva delicatamente dal manico.

### MANUTENZIONE

- **Pulizia:** Pulisci il capotasto regolarmente con un panno morbido e asciutto. Per i modelli in metallo, puoi utilizzare un panno leggermente umido con un detergente neutro, evitando prodotti corrosivi.
- **Controllo del meccanismo:** Controlla periodicamente la molla o la vite di fissaggio per garantire un funzionamento fluido e sicuro.
- **Protezione della gomma o del silicone:** Evita di esporre il capotasto a temperature estreme o umidità eccessiva, che potrebbero compromettere il materiale di protezione delle corde.

### SICUREZZA

- **Pressione adeguata:** Non stringere eccessivamente il capotasto per evitare danni alla tastiera della chitarra.
- **Manipolazione corretta:** Evita di applicare o rimuovere il capotasto con movimenti bruschi che potrebbero graffiare lo strumento.
- **Conservazione:** Quando non in uso, conserva il capotasto in una custodia o in un luogo asciutto per evitare l'usura prematura dei materiali.
- **Utilizzo su strumenti diversi:** Se usi il capotasto su più strumenti, assicurati che la misura e il sistema di bloccaggio siano compatibili con ognuno di essi.

Grazie per aver scelto Soundsation! Per ulteriori dettagli e assistenza, visita il sito ufficiale o contatta il rivenditore autorizzato.

### AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPSR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneggiato o con parti mancanti
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

### GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio.

Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso.



Inquadra il QR-Code per scaricare la documentazione del prodotto.

Smaltire il prodotto e il suo imballaggio in modo responsabile, secondo le normative locali per il riciclo e la protezione ambientale

Made in/Prodotto in/Hecho en China for Soundsation  
Imported by/Importato da/Importato de in EU by  
FRENEXPOR SpA  
Via Enzo Ferrari,10 - 62017 Porto Recanati – Italy  
frenexport.it - contact@frenexport.it

Soundsation® is a registered trademark of FRENEXPOR SPA - Italy  
Soundsation® è un marchio di fabbrica registrato della FRENEXPOR SPA - Italy





Thank you for choosing our product!



## SOUNDSATION CAPOS – USER MANUAL

The Soundsation capo is an essential accessory for guitarists and musicians who want to quickly change the tuning of their instrument. Available in universal versions or specific models for acoustic and electric guitars, it can be made of metal or plastic depending on the model. This manual provides instructions on use, maintenance, and safety to ensure optimal performance and long-lasting durability.

### TECHNICAL SPECIFICATIONS

- **Type:** Universal or specific for acoustic/electric guitar (depending on the model)
- **Material:** Metal or plastic (depending on the model)
- **Locking system:** Spring-loaded or screw-based for a stable and secure grip
- **Internal lining:** Rubber or silicone to protect the guitar's fretboard

### USAGE

- **Applying to the neck:** Open the capo and place it on the fretboard in the desired position.
- **Fastening:** If the model is spring-loaded, press and gently release for immediate fastening. If the model has a screw mechanism, gradually tighten until you achieve a firm grip without applying excessive pressure.
- **Stability check:** Ensure that the capo is securely fastened and that all strings sound clearly without unwanted vibrations.
- **Removal:** To remove the capo, loosen the grip and gently lift it off the neck.

### MAINTENANCE

- **Cleaning:** Regularly clean the capo with a soft, dry cloth. For metal models, you can use a slightly damp cloth with a neutral detergent, avoiding corrosive products.
- **Mechanism check:** Periodically inspect the spring or screw mechanism to ensure smooth and secure operation.
- **Protection of rubber or silicone:** Avoid exposing the capo to extreme temperatures or excessive humidity, which could compromise the protective material for the strings.

### SAFETY

- **Proper pressure:** Do not overtighten the capo to avoid damaging the guitar's fretboard.
- **Correct handling:** Avoid applying or removing the capo with abrupt movements that could scratch the instrument.
- **Storage:** When not in use, store the capo in a case or a dry place to prevent premature wear of materials.
- **Use on different instruments:** If using the capo on multiple instruments, ensure that the size and locking system are compatible with each of them.

Thank you for choosing Soundsation! For more details and support, visit the official website or contact an authorized dealer.

## GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

## WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use. For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.

Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection

Made in/Prodotto in/Hecho en China for Soundsation  
Imported by/Importato da/Importato de in EU by  
FRENEXPOR SpA  
Via Enzo Ferrari,10 - 62017 Porto Recanati – Italy  
frenexport.it - contact@frenexport.it

Soundsation® is a registered trademark of FRENEXPOR SPA - Italy  
Soundsation® è un marchio di fabbrica registrato della FRENEXPOR SPA - Italy

