



Grazie per aver scelto il nostro prodotto!



Clave in Legno SCW-SC1

Grazie per aver scelto le nostre clave in legno. Questi strumenti semplici ed efficaci sono ideali per l'apprendimento della ritmica in contesti scolastici, ma anche per l'uso in ensemble e performance musicali. Le clave in legno offrono un suono chiaro e nitido, perfetto per accompagnare qualsiasi tipo di musica.

CONTENUTO DELLA CONFEZIONE

- 1 coppia di clave in legno (2 pezzi).
- 1 Manuale d'istruzioni.

ISTRUZIONI PER L'USO

- Tieni una clave saldamente con una mano, posizionandola orizzontalmente come base.
- Con l'altra mano, utilizza la seconda clave per percuotere quella fissa.
- Colpisci delicatamente al centro per produrre un suono chiaro e risonante.
- Sperimenta ritmi diversi e prova a variare intensità e velocità per scoprire nuovi pattern ritmici.

MANUTENZIONE E CONSERVAZIONE

- **Pulizia:**
 - Utilizza un panno morbido asciutto per rimuovere polvere e impronte.
 - Per una pulizia più approfondita, utilizza un panno leggermente umido e asciuga immediatamente.
- **Conservazione:**
 - Riponi le clave in un luogo asciutto e al riparo da umidità o calore eccessivo.
 - Evita di lasciarle a contatto con superfici abrasive per evitare graffi.

AVVERTENZE DI SICUREZZA

- Non adatto a bambini di età inferiore ai 3 anni.
- Utilizza le clave sotto supervisione di un adulto durante l'uso scolastico.
- Non utilizzare le clave su superfici dure per evitare danneggiamenti.

AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPSR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneggiato o con parti mancanti
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio. Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso.



Inquadra il QR-Code per scaricare la documentazione del prodotto.

Smaltire il prodotto e il suo imballaggio in modo responsabile, secondo le normative locali per il riciclo e la protezione ambientale

Made in/Prodotto in/Hecho en China for Soundstation
Imported by/Importato da/Importato de in EU by
FRENEEXPORT SpA

Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy
frenexport.it - contact@frenexport.it

Soundstation® is a registered trademark of FRENEEXPORT SPA - Italy
Soundstation® è un marchio di fabbrica registrato della FRENEEXPORT SPA - Italy





Thank you for choosing our product!



Wooden Club SCW-SC1

Thank you for choosing our wooden claves. These simple and effective instruments are ideal for learning rhythm in school settings, as well as for use in ensembles and musical performances. Wooden claves produce a clear and crisp sound, perfect for accompanying any type of music.

PACKAGE CONTENTS

- 1 pair of wooden claves (2 pieces).
- 1 Instruction manual.

INSTRUCTIONS FOR USE

- Hold one clave firmly in one hand, positioning it horizontally as a base.
- Use the other clave in the other hand to strike the stationary one.
- Strike gently at the center to produce a clear, resonant sound.
- Experiment with different rhythms, varying intensity and speed to create new rhythmic patterns.

MAINTENANCE AND STORAGE

- **Cleaning:**
 - Use a soft, dry cloth to remove dust and fingerprints.
 - For deeper cleaning, use a slightly damp cloth and dry immediately.
- **Storage:**
 - Riponi le clave in un luogo asciutto e al riparo da umidità o calore eccessivo.
 - Evita di lasciarle a contatto con superfici abrasive per evitare graffi.

SAFETY WARNINGS

- Not suitable for children under 3 years of age.
- Use the claves under adult supervision in school settings.
- Avoid using the claves on hard surfaces to prevent damage.

GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use. For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.

Made in/Prodotto in/Hecho en China for SoundSation
Imported by/Importato da/Importato de in EU by
FRENEEXPORT SpA
Via Enzo Ferrari, 10 - 62017 Porto Recanati – Italy
frenexport.it - contact@frenexport.it
SoundSation® is a registered trademark of FRENEEXPORT SPA - Italy
SoundSation® è un marchio di fabbrica registrato della FRENEEXPORT SPA - Italy



Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection