



Grazie per aver scelto il nostro prodotto!



Glockenspiel SG-30N Professionale Cromatico

Grazie per aver scelto il Glockenspiel SG-30N. Questo strumento professionale è progettato per musicisti e appassionati, offrendo un'estesa gamma cromatica di 30 note (dal Sol al Do) e una struttura di alta qualità. La base in legno garantisce stabilità e un suono caldo e bilanciato, mentre il design ripiegabile e la borsa inclusa lo rendono ideale per il trasporto e l'uso quotidiano.

CONTENUTO DELLA CONFEZIONE

- 1 Glockenspiel SG-30N con 30 barre in metallo (scala cromatica dal Sol al Do).
- 2 Bacchette per la percussione.
- 1 Borsa per il trasporto in tessuto imbottito con maniglie.
- 1 Manuale d'istruzioni.
- Certificato di garanzia.

ISTRUZIONI PER L'USO

- **Preparazione e montaggio:**
 - Apri con attenzione il glockenspiel utilizzando le cerniere laterali. Assicurati che la base in legno sia completamente distesa e stabile.
 - Posiziona lo strumento su una superficie piana per ottimizzare la resa acustica.
- **Uso delle bacchette:**
 - Utilizza le bacchette incluse per suonare le barre in metallo.
 - Colpisci delicatamente il centro delle barre per ottenere un suono chiaro e uniforme.
- **Trasporto:**
 - Dopo l'uso, richiudi lo strumento ripiegandolo seguendo le cerniere.
 - Riponi il glockenspiel nella borsa per proteggerlo durante il trasporto.

MANUTENZIONE E CONSERVAZIONE

- **Pulizia:**
 - Pulisci le barre con un panno morbido e asciutto per rimuovere polvere e impronte.
 - La base in legno può essere pulita con un panno leggermente inumidito; asciugare immediatamente.
- **Conservazione:**
 - Conserva il glockenspiel in un ambiente asciutto, lontano da umidità e temperature estreme.
 - Utilizza sempre la borsa per evitare graffi o danni durante il trasporto.

AVVERTENZE DI SICUREZZA

- Questo prodotto non è adatto a bambini di età inferiore ai 3 anni a causa di piccole parti e bordi taglienti.
- Utilizza il glockenspiel solo per scopi musicali.
- Evita di esercitare una forza eccessiva sulle barre in metallo per non danneggiarle.
- Non lasciare il glockenspiel esposto a fonti di calore diretto o umidità.

AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPSR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneggiato o con parti mancanti.
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio. Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso.



Inquadra il QR-Code per scaricare la documentazione del prodotto.

Smaltire il prodotto e il suo imballaggio in modo responsabile, secondo le normative locali per il riciclo e la protezione ambientale

Made in/Prodotto in/Hecho en China for Soundstation
Imported by/Importato da/Importato de in EU by
FRENEEXPORT SpA

Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy
frenexport.it - contact@frenexport.it

Soundstation® is a registered trademark of FRENEEXPORT SPA - Italy
Soundstation® è un marchio di fabbrica registrato della FRENEEXPORT SPA - Italy





Thank you for choosing our product!



Glockenspiel SG-30N Professional Chromatic

Thank you for choosing the Glockenspiel SG-30N. This professional instrument is designed for musicians and enthusiasts, offering an extended chromatic range of 30 notes (from G to C) and a high-quality structure. The wooden base ensures stability and a warm, balanced sound, while the foldable design and included carrying bag make it perfect for transport and everyday use.

PACKAGE CONTENTS

- 1 Glockenspiel SG-30N with 30 metal bars (chromatic scale from G to C).
- 2 Percussion mallets.
- 1 Padded fabric carrying bag with handles.
- 1 Instruction manual.
- Warranty certificate.

INSTRUCTIONS FOR USE

- **Setup and assembly:**
 - Carefully open the glockenspiel using the side hinges. Ensure the wooden base is fully extended and stable.
 - Place the instrument on a flat surface to optimize acoustic performance.
- **Using the mallets:**
 - Use the included mallets to play the metal bars.
 - Gently strike the center of the bars to produce a clear and consistent sound.
- **Transportation:**
 - After use, fold the instrument following the hinges.
 - Store the glockenspiel in the bag to protect it during transport.

MAINTENANCE AND STORAGE

- **Cleaning:**
 - Clean the bars with a soft, dry cloth to remove dust and fingerprints.
 - The wooden base can be wiped with a slightly damp cloth; dry immediately.
- **Storage:**
 - Store the glockenspiel in a dry environment, away from moisture and extreme temperatures.
 - Always use the bag to prevent scratches or damage during transport.

SAFETY WARNINGS

- This product is not suitable for children under 3 years of age due to small parts and sharp edges.
- Use the glockenspiel only for musical purposes.
- Avoid applying excessive force to the metal bars to prevent damage.
- Do not expose the glockenspiel to direct heat sources or moisture.

GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use. For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.

Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection

Made in/Prodotto in/Hecho en China for Soundstation
Imported by/Importato da/Importato de in EU by
FRENEXPOR SpA

Via Enzo Ferrari, 10 - 62017 Porto Recanati – Italy
frenexport.it - contact@frenexport.it

Soundstation® is a registered trademark of FRENEXPOR SPA - Italy
Soundstation® è un marchio di fabbrica registrato della FRENEXPOR SPA - Italy

