



Grazie per aver scelto il nostro prodotto!



SOUNDSATION CHS-300 HI-HAT STAND - MANUALE D'USO

Grazie per aver scelto la nostra asta hi-hat per batteria CHS-300. Questo prodotto è progettato per offrire massima reattività, stabilità e durata durante l'esecuzione. Prima di utilizzare il prodotto, leggere attentamente questo manuale per garantire un uso corretto e sicuro.

CONTENUTO DELLA CONFEZIONE

- 1 asta hi-hat
- 1 manuale d'istruzioni

SPECIFICHE TECNICHE DEL PRODOTTO

- Tipo: Asta hi-hat
- Gambe: Double braced
- Sistema di trazione: A catena
- Altezza: Minima 77 cm, massima 87 cm
- Peso: 2,4 Kg
- Pedale antiscivolo incluso

MODI D'USO

- Posizionare l'asta hi-hat su una superficie stabile e piana.
- Aprire le gambe double braced fino a raggiungere una base solida.
- Regolare l'altezza del tubo centrale secondo la propria configurazione preferita e stringere bene il meccanismo di bloccaggio.
- Inserire il piatto inferiore sul supporto fisso.
- Montare il piatto superiore sull'asta mobile e fissarlo con il clutch.
- Collegare la catena del pedale alla leva di trasmissione.
- Verificare che il pedale risponda correttamente alla pressione prima di suonare.

MANUTENZIONE E PULIZIA

- Pulire regolarmente l'asta con un panno morbido e asciutto per rimuovere polvere e sporco.
- Lubrificare la catena e le parti mobili periodicamente per garantire un funzionamento fluido.
- Controllare lo stato del clutch, della molla e del pedale per rilevare eventuali segni di usura.

AVVERTENZE SPECIFICHE DEL PRODOTTO

- Non utilizzare l'asta su superfici irregolari o scivolose.
- Evitare di applicare una forza eccessiva sul pedale.
- Assicurarsi che tutti i componenti (clutch, piatti, catena) siano correttamente fissati prima dell'uso.
- Non esporre il prodotto a umidità eccessiva o condizioni meteorologiche avverse.
- Con la dovuta manutenzione, la vostra asta hi-hat CHS-300 garantirà performance affidabili per lungo tempo.

AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPSR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneggiato o con parti mancanti
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio. Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso.



Inquadra il QR-Code per scaricare la documentazione del prodotto.

Made in/Prodotto in/Hecho en China for Soundstation
Imported by/Importato da/Importato de in EU by
FRENEXPOR SpA
Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy
frenexport.it - contact@frenexport.it

Soundstation® is a registered trademark of FRENEXPOR SPA - Italy
Soundstation® è un marchio di fabbrica registrato della FRENEXPOR SPA - Italy

Smaltire il prodotto e il suo imballaggio in modo responsabile, secondo le normative locali per il riciclo e la protezione ambientale





Thank you for choosing our product!



SOUNDSATION CHS-300 HI-HAT STAND - USER MANUAL

Thank you for choosing our CDS-100 adjustable cello and double bass stand. Designed to offer maximum stability and protection, this stand is ideal for various instrument sizes thanks to its three-point adjustment system. The foldable design ensures easy transport and storage. Please read this manual carefully before use to ensure safe and proper handling.

PACKAGE CONTENTS

- 1 CDS-100 adjustable stand
- 1 instruction manual

PRODUCT SPECIFICATIONS

- Material: Sturdy metal construction
- Adjustment points: 3
- Contact points: Anti-scratch material coating
- Bow holder hook: Included
- Neck holder height (from ground): 83 – 148 cm
- Base dimensions (W x D min-max): 400 x 350 – 580 mm
- Weight: 3.45 kg

USAGE INSTRUCTIONS

- Unfold the stand on a stable, flat surface.
- Adjust the base to the desired size to ensure a secure hold for your instrument.
- Set the neck holder height to fit your cello or double bass.
- Place the instrument on the stand, ensuring all contact points are aligned and cushioned.
- Hang the bow on the included hook to keep it safe and accessible.

MAINTENANCE AND CLEANING

- Wipe the stand regularly with a dry cloth to remove dust and debris.
- Periodically check all adjustment points to ensure secure positioning.
- Ensure anti-scratch pads are intact and not worn out.
- Fold and store the stand in a dry place when not in use.

PRODUCT-SPECIFIC WARNINGS

- Do not exceed the specified adjustment limits to avoid instability.
- Never leave the instrument unattended on the stand in high-traffic or unstable areas.
- Always verify that the stand is fully opened and stable before placing the instrument.
- Do not use the stand on slanted or slippery surfaces.

GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use.

For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.

Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection

Made in/Prodotto in/Hecho en China for SoundSation
Imported by/Importato da/Importato de in EU by
FRENEXPORt SpA
Via Enzo Ferrari,10 - 62017 Porto Recanati – Italy
frenexport.it - contact@frenexport.it

SoundSation® is a registered trademark of FRENEXPORt SPA - Italy
SoundSation® è un marchio di fabbrica registrato della FRENEXPORt SPA - Italy

