



Grazie per aver scelto il nostro prodotto!



UKULELE SOUNDSATION – MANUALE UTENTE

Grazie per aver scelto un ukulele Soundsation! La vasta gamma di ukulele Soundsation comprende diverse serie, ognuna con finiture e caratteristiche uniche, pensate per soddisfare le esigenze di musicisti di ogni livello. Che tu sia un principiante o un suonatore esperto, troverai uno strumento che combina suonabilità, qualità e stile.

Le serie disponibili includono modelli soprano, concerto, tenore e baritono, realizzati con diversi legni in differenti finiture.

Gli ukulele Soundsation sono strumenti versatili, ideali per accompagnare il canto, suonare melodie o esplorare nuove sonorità in modo semplice e divertente.

MANUTENZIONE E PULIZIA

Per garantire che il tuo ukulele Soundsation mantenga la sua qualità nel tempo, è importante seguire alcune semplici pratiche di manutenzione:

PULIZIA

Dopo ogni utilizzo, pulisci lo strumento con un panno morbido e asciutto per rimuovere polvere, impronte e residui di sudore.

Evita l'uso di prodotti chimici aggressivi. Se necessario, utilizza detergenti specifici per strumenti musicali.

CORDE

Controlla regolarmente le corde e sostituiscile quando iniziano a perdere brillantezza o elasticità.

Durante il cambio delle corde, pulisci la tastiera con un panno asciutto per rimuovere eventuali residui.

ACCORDATURA

Gli ukulele, soprattutto se nuovi, richiedono qualche giorno per stabilizzarsi. Accordali regolarmente per mantenere l'intonazione corretta.

AVVERTENZE DI SICUREZZA

- Conserva l'ukulele in un luogo asciutto, lontano da fonti di calore e umidità, che potrebbero deformare il legno.
- Usa una custodia imbottita per proteggere lo strumento durante gli spostamenti.
- Evita urti e pressioni eccessive sul corpo e sul manico dello strumento.
- Controlla periodicamente che le chiacchette di accordatura siano ben serrate, senza forzare.

Grazie per aver scelto Soundsation! Per ulteriori dettagli e assistenza, visita il sito ufficiale o contatta il rivenditore autorizzato.

AVVERTENZE GENERALI SULLA SICUREZZA

- Questo prodotto è stato progettato e testato per soddisfare i requisiti di sicurezza definiti dalla normativa GPCR (General Product Safety Regulation) dell'Unione Europea.
- Si prega di utilizzare questo prodotto solo secondo le indicazioni fornite nel manuale d'uso per garantire la sicurezza.
- L'uso di questo prodotto da parte dei bambini e delle persone vulnerabili deve sempre avvenire sotto la supervisione di un adulto responsabile.
- Non utilizzare il prodotto su superfici irregolari.
- Utilizzare il prodotto solo in ambienti asciutti con una temperatura compresa tra 5°C e 35°C.
- Non esporre a umidità, polvere, fiamme vive o luce solare diretta.
- Non utilizzare il prodotto se visibilmente danneggiato o con parti mancanti
- Non utilizzare come strumento per salire o sostenere carichi dinamici.
- L'uso inappropriato può causare danni al prodotto e rischi per la sicurezza.

GARANZIA E ASSISTENZA

Questo prodotto è coperto da una garanzia di 2 anni contro i difetti di fabbricazione. La garanzia non copre i danni causati da usura normale o uso improprio.

Per assistenza post vendita ti preghiamo di contattare il tuo rivenditore che saprà fornire tutte le istruzioni del caso.



Inquadra il QR-Code per scaricare la documentazione del prodotto.

Smaltire il prodotto e il suo imballaggio in modo responsabile, secondo le normative locali per il riciclo e la protezione ambientale

Made in/Prodotto in/Hecho en China for Soundsation
Imported by/Importato da/Importato de in EU by
FREXEXPORT SpA
Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy
frenexport.it - contact@frenexport.it

Soundsation® is a registered trademark of FREXEXPORT SPA - Italy
Soundsation® è un marchio di fabbrica registrato della FREXEXPORT SPA - Italy





Thank you for choosing our product!



SOUNDSATION UKULELE – USER MANUAL

Thank you for choosing a Soundsation ukulele! The wide range of Soundsation ukuleles includes different series, each with unique finishes and features designed to meet the needs of musicians at every level.

Whether you're a beginner or an experienced player, you'll find an instrument that combines playability, quality, and style.

The available series include soprano, concert, tenor, and baritone models, made from various woods with different finishes.

Soundsation ukuleles are versatile instruments, perfect for accompanying singing, playing melodies, or exploring new sounds in a simple and fun way.

MAINTENANCE AND CLEANING

To ensure that your Soundsation ukulele maintains its quality over time, it's important to follow a few simple maintenance practices:

CLEANING

After each use, clean the instrument with a soft, dry cloth to remove dust, fingerprints, and sweat residues. Avoid using aggressive chemical products. If necessary, use specific cleaners for musical instruments.

STRINGS

Regularly check the strings and replace them when they start to lose brightness or elasticity.

During string changes, clean the fingerboard with a dry cloth to remove any residue.

TUNING

Ukuleles, especially new ones, take a few days to stabilize. Tune them regularly to maintain proper intonation.

SAFETY WARNINGS

- To protect your ukulele and play safely, follow these guidelines:
- Store the ukulele in a dry place, away from heat and humidity, which could warp the wood.
- Use a padded case to protect the instrument during transport.
- Avoid excessive pressure and impacts on the body and neck of the instrument.
- Regularly check that the tuning pegs are properly tightened without forcing them.

Thank you for choosing Soundsation! For more details and support, visit the official website or contact an authorized dealer.

GENERAL SAFETY WARNINGS

- This product has been designed and tested to meet the safety requirements set out in the European Union General Product Safety Regulation (GPSR).
- Please use this product only as directed in the user manual to ensure safety.
- Use of this product by children and vulnerable people must always be under the supervision of a responsible adult.
- Do not use the product on uneven surfaces.
- Use the product only in dry environments with a temperature between 5°C and 35°C.
- Do not expose to moisture, dust, naked flames or direct sunlight.
- Do not use the product if it is visibly damaged or missing parts
- Do not use as a tool for climbing or supporting dynamic loads.
- Inappropriate use may cause damage to the product and safety risks.

WARRANTY AND ASSISTANCE

This product comes with a 2-year warranty against manufacturing defects. The warranty does not cover damage caused by normal wear and tear or improper use.

For after-sales assistance, please contact your retailer, who will provide the necessary instructions.



Scan the QR code to download the product documentation.

Dispose of the product and its packaging responsibly, according to local regulations for recycling and environmental protection

Made in/Prodotto in/Hecho en China for Soundsation

Imported by/Importato da/Importato de in EU by FRENEXPORT SpA

Via Enzo Ferrari,10 - 62017 Porto Recanati – Italy
frenexport.it - contact@frenexport.it

Soundsation® is a registered trademark of FRENEXPORT SPA - Italy
Soundsation® è un marchio di fabbrica registrato della FRENEXPORT SPA - Italy

