


# How to install a Style expansion pack file to your AK series keyboard


1. Copy the expansion file (.mpk or .mps) to a USB stick.

**Note:** Please make sure USB stick is safely ejected before you unplug it.


2. Insert the USB stick to the [USB to DEVICE] jack on the back panel.




3. Press USB ([MIXER] + [FUNCTION] on the panel), select “Load” menu.



4. Select “ExpStyle,” then find the file name you wish to install – i.e. “AK603 ExpansionYYMMDD.mpk.”



5. Press “Enter” to execute. The LCD will display “Wait ..” until the installation is complete.



6. Check that the installed styles are found in the User area of the library.

**Note:** Do not disconnect the USB device during installation.

Please keep the instrument power supply on. Otherwise, your expansion data will be damaged. The current expansion data will be overwritten if you install a new expansion file.